

LÍNEA **THERMAL
DYNAMICS**
AN ESAB® BRAND

LÍNEA **THERMAL DYNAMICS**

AN ESAB® BRAND


Nº	System	Order N°	Description
1	PCH M51	TH 9-5631	Tip
2		TH 9-5633	Electrode




Nº	System	Order N°	Description
1	PCH M52	TH 9-5618	Tip,45A
1		TH 9-5702	Tip,35A
1		TH 9-5707	Tip,70A
1		TH 9-5782	Tip,80A
2		TH 9-5708 TH 9-5619	Tip,100A Electrode,Air




Nº	System	Order N°	Description
1	PCH M102	TH 8-7514	Tip,50-60A
1		TH 9-7726	Tip,60A
1		TH 9-7728	Tip, 80Amp
2		TH 9-8402	Electrode
3		TH 9-8407	Electrode



NO	System	Order N°	Description
1	PCH M120	TH 20-1221	Tip,70A
1		TH 20-1222	Tip,120A
2		TH 20-1210	Electrode



NO	System	Order N°	Description
1	XT 301	TH 36-1027	Shield 100A
2		TH 36-1053	Tip 100A
3		TH 36-1071	Electrode 100A
4		TH 36-1028	Shield 200A
5		TH 36-1055	Tip 200A
6		TH 36-1085	Electrode 200A



LÍNEA THERMAL DYNAMICS

AN ESAB BRAND

Nº	System	Order Nº	Description
1		TH 9-8215	Electrode
2		TH 9-8211	Tip,80A
2		TH 9-8212	Tip,100A
2		TH 9-8205	Tip,20A
2		TH 9-8206	Tip,30A
2		TH 9-8207	Tip,40A
2		TH 9-8208	Tip,40A
2		TH 9-8209	Tip,50/55A
2		TH 9-8210	Tip,60A
6		TH 9-8218	Shield Cup
		TH 9-9219	Torch Head
6		TH 9-8243	Shield Cap Deflector
6		TH 9-8235	Shield Cap 50-60A
		TH 9-8236	Shield Cap 70A
6		TH 9-8237	Shield Cup
		TH 9-8231	Tip,70A,Cutting
5		TH 9-8213	Start Cartridge
	SL60 SL100	TH 9-8253	Nozzle 120A
1		TH 9-8232	Electrode
4		TH 9-8245	Shield Cap,40A
4		TH 9-8238	Shield Cap,50-60A
4		TH 9-8239	Shield Cap,70-100A
4		TH 9-8256	Shield Cap,120A
		TH 9-8220	Cuerpo Torch Manual
		TH 9-8220	Torch Manual SL40 4,5 M
		TH 7-0040	Torch Manual SL60 4,5 M
		TH 7-5204	Torch Recta SL100 7,6 M
		TH 7-5215	Cuerpo Torch Machine
		TH 9-9445	Empu. Torch Machine SL 100
		TH 4-3058	Cable Torch Machine 7,6
		TH 03322	Empu. Torch Hand vvaSL 60

